

1



Items required:  
Styroscrew anchors, suitable  
6g, 7g or 8g screw, Phillips  
driver bit, cordless drill.

2



Using a Phillips driver bit,  
screw the Styroscrew anchor  
into the board until the flange  
is firmly against the board.

3



Place the clip or bracket over  
the Styroscrew anchor and  
secure with the metal screw  
you have selected.